












AROSA 570 G PREMIUM STEEL

A





A			LOGO AND HANDLE	LOGO UND GRIFF
Pos.	Art. Nr.	Description	Beschreibung	
A1	18.371.03	Protection washer	Schutz-Unterlagsscheibe	
A2	18.371.57	Washer	Unterlagsscheibe	
A3	18.370.48	Nut	Mutter	
A4	18.371.72	Screw	Schraube	
A5	18.370.76	Protection washer	Schutz-Unterlagsscheibe	

B



B			SMALL BURNER	KLEINER BRENNER
Pos.	Art. Nr.	Description	Beschreibung	
B1	18.370.03	Screw	Schraube	
B2	18.371.38	Washer	Unterlagsscheibe	
B3	18.371.66	Nut	Mutter	






C



C			BURNER	BRENNER
Pos.	Art. Nr.	Description	Beschreibung	
C1	18.370.07	Screw	Schraube	
C2	18.371.16	Washer	Unterlagsscheibe	
C3	18.371.17	Protection washer	Schutz-Unterlagsscheibe	
C4	18.370.68	Washer	Unterlagsscheibe	
C5	18.371.19	Dome nut	Hutmutter	


AROSA 570 G PREMIUM STEEL

D




D		IGNITION	ZÜNDUNG
Pos.	Art. Nr.	Description	Beschreibung
D1	18.371.62	Screw	Schraube
D2	18.371.80	Washer	Unterlagsscheibe
D3	18.371.81	Screw	Schraube


E



1





2



E			BURNER SUPPORT / BOWL	BRENNER HALTERUNG / KUGEL
Pos.	Art. Nr.	Description	Beschreibung	
E1	18.371.61	Screw	Schraube	
E2	18.371.17	Protection washer	Schutz-Unterlagscheibe	
E3	18.371.62	Screw	Schraube	



F



F			SIDE BURNER	SEITENBRENNER
Pos.	Art. Nr.	Description	Beschreibung	
F1	18.371.62	Screw	Schraube	



AROSA 570 G PREMIUM STEEL

G





G	PIEZO ELECTRODE SIDE BURNER		PIEZO ELEKTRODE SEITENBRENNER
Pos.	Art. Nr.	Description	Beschreibung
G1	18.371.62	Screw	Schraube

H




H	KNOB / FRAME		DREHKNOPF / RING
Pos.	Art. Nr.	Description	Beschreibung
H1	18.371.37	Screw	Schraube
H2	18.371.79	Screw	Schraube





I		IGNITION	ZÜNDUNGSBOX
Pos.	Art. Nr.	Description	Beschreibung
I1	18.371.63	Screw	Schraube


AROSA 570 G PREMIUM STEEL


18.379.49

Washer		
3x	bc	
18.371.77		


Clip bearing		
2x	be	
18.371.82		


Wheel cap		
2x		
18.360.92		


M5 x 13		
9x	xx	
18.371.84		


Washer M5		
1x	ak	
18.371.38		

Spring washer M5		
1x	bd	
18.371.65		

Nut M5		
1x	bb	
18.371.66		


M6 X 13		
4x	xv	
18.371.83		


M6 X 13		
9x	xo	
18.371.72		

M6 X 18		
24x	xr	
18.371.61		


M5 X 13		
5x	xp	
18.371.62		


Teflon washer		
8x	z	
18.370.76		


M5 X 10		
8x	xn	
18.371.68		


Accessory Pin		
6x		
18.324.49		


Protection Foil Accessory Insert		
10x		
18.361.02		


Cable Tree Fixation Clips		
5x	an	
18.371.43		


Crosshead Screwdriver B (85mm)		
1x	as	
18.371.49		


Open End Wrench (S17 + S19)		
2x	ap	
18.371.46		

Open End Wrench (S13 + S8)		
1x	ba	
18.371.78		

Socket Wrench M5		
1x	at	
18.371.69		

Screwdriver M5		
1x	ay	
18.371.75		


Screwdriver M6		
1x	az	
18.371.76		

Clip bearing		
2x		
18.371.85		



NON Rechargeable Battery 1.5V (AAA)		
8x		


AROSA 570 G PREMIUM STEEL

1.




2.


ba x1 		az x1 	
bc x3 	be x2 	xo x1 	18.360.92 x2 



AROSA 570 G PREMIUM STEEL


3.

ba x1 	ay x1 		
ak x1 	bd x1 	bb x1 	xx x1 





4.



az x1 	xv x4 
--	---



5.





6.






AROSA 570 G PREMIUM STEEL




7.




8.




9.





xr



10.




1



2

18.361.02






AROSA 570 G PREMIUM STEEL



11.





1



12.






13.





AROSA 570 G PREMIUM STEEL




14.





15.



16.






17.





AROSA 570 G PREMIUM STEEL



18.




19.




20.




21.




AROSA 570 G PREMIUM STEEL


22.  x2  AAA x2 





23.  x1  AAA x6 



24.




25.




AROSA 570 G PREMIUM STEEL

26.




27.

1



27.

2



TO TAKE NOTES

[illegible]

SPAREPARTS			ERSATZTEIL-LISTE
Pos.	Art. Nr.	Description	Beschreibung
1	18.350.96	Lid, black	Deckel, schwarz
2	18.324.11	Lid handle cubic	Deckelgriff cubic
3	18.850.23	Heat indicator °C/°F	Temperatur Anzeiger °C/°F
4	18.822.55	Logo	Logo
5	18.324.12	Lid hinge set	Deckelscharnier Set
6	14.112.62	Cooking grid stainless steel	Grillrost Edelstahl
7	18.324.08	Large funnel	Grosser Trichter
8	18.320.03	Small funnel	Kleiner Trichter
9	18.341.13	Burner small 30mbar	Kleiner Brenner 30mbar
9	18.341.14	Burner small 50mbar	kleiner Brenner 50mbar
10	18.341.20	Burner large 30mbar	Grosser Brenner 30mbar
10	18.341.21	Burner large 50mbar	Grosser Brenner 50mbar
11	18.341.23	Flame guard small burner 30 mbar	Flamenwächter Brenner klein 30 mbar
11	18.341.25	Flame guard small burner 50 mbar	Flamenwächter Brenner klein 50 mbar
12	18.341.24	Flame guard large burner 30 mbar	Flamenwächter Brenner gross 30 mbar
12	18.341.26	Flame guard large burner 50 mbar	Flamenwächter Brenner gross 50 mbar
13	18.324.70	Cap flame guard small burner	Kappe Flamenwächter Brenner klein
14	18.324.71	Cap flame guard large burner	Kappe Flamenwächter Brenner gross
15	18.341.19	Burnerfixation DB small	Fixierring DB klein
16	18.350.98	Bowl, black	Kugel, schwarz
17	18.324.52	Protection bowl	Schutzkugel
18	18.323.04	Drip pan	Fettauffangschale
19	18.323.05	Drip pan carrier	Fettauffangschale Halterung
20	18.360.90	Control knob safety light	Gasregulierknopf mit Kontrolllicht
21	18.730.14	Pulse ignition (3 outputs)	Elektrozündung (3 Ausgänge)
22	18.324.67	Side table	Seitentablar
23	18.324.17	Accessory pin (set of 2 piece)	Zubehör Pin (Set mit 2 Stück)
24	18.324.68	Side burner table	Seitenbrenner Tisch
25	18.324.24	Side burner grate	Rost zu Seitenbrenner
26	18.324.25	Wok bracket	Wokhalterung
27	18.341.15	Side burner 50 mbar	Seitenbrenner 50 mbar
27	18.341.16	Side burner 30 mbar	Seitenbrenner 30 mbar
28	18.341.22	Piezo electrode side burner incl. wire	Piezo-Elektrode Seitenbrenner inkl. Kabel
29	18.324.65	Stiffener A	Strebe A
30	18.324.66	Stiffener B	Strebe B
31	18.324.61	Right side panel 304	Rechte Seitenwand 304
32	18.324.62	Left side panel 304	Linke Seitenwand 304
33	18.324.56	Door	Türe
34	18.324.57	Door handle	Türgriff
35	18.324.64	Bottle jacket	Flaschenschale
36	18.324.55	Accessory insert	Zubehör Einsatz
37	18.324.63	Bottom plate	Bodenplatte
38	18.361.03	Wheel warm white	Rad warm weiss
39	18.360.92	Wheel cap	Rad Kappe
40	18.360.37	Height adjustment	Höhenverstellung

SPAREPARTS			ERSATZTEIL-LISTE
Pos.	Art. Nr.	Description	Beschreibung
41	18.379.49	Hardware set	Schraubenset
42	18.360.86	Protection pin	Schutzstift
43	18.360.94	Spacer	Schutzstift Distanz
44	18.360.95	Protection pin	Puffer Seitentablar
45	18.360.96	Protection ring	Schutzring
46	18.371.85	Clip Bearing	Klammerlager
47	18.361.00	Protection foil gas tank	Schutzfolie Gasflasche
48	18.361.02	Protection foil accessory insert	Schutzfolie Zubehör Einsatz
49	14.911.62	Adapter 5/8"UNF- 1/4"LH	Adapter 5/8"UNF - 1/4"LH
50	individual	Gas hose	Gasschlauch
51	individual	Gas regulator	Gasdruck-Regler
52	18.325.00	Wheel axle / black	Radachse / schwarz

Lesen Sie die Bedienungsanleitung sorgfältig durch, bevor Sie Ihren **OUTDOORCHEF** Grill in Betrieb nehmen.
 Please read the user guide carefully before using your **OUTDOORCHEF** Barbeque.

Attention

Please write your serial number on the backside of the manual for future reference. You will find the number on the data plate attached to the trolley or the bottom plate depending on the grill model. **OUTDOORCHEF** can only supply spare parts and honour warranty returns when the serial number is available.

Achtung

Bitte notieren Sie auf der Rückseite Ihrer Gebrauchsanweisung die Serien-Nummer. Je nach Grillmodell finden Sie die Nummer auf dem Datensticker, welcher sich entweder am Grillgestell oder auf der Bodenplatte befindet. **OUTDOORCHEF** kann Garantie und Ersatzteillieferungen nur mit der Serien-Nummer bearbeiten.

Outdoorchef AG operates a policy of continuous product development and improvement.

As such we reserve the right to alter product design and or technical specification without giving any prior notice.